

# **Raffaello Series**



HIGH PRESSURE HOMOGENIZERS AND PLUNGER PUMPS SINCE 1974

## Model HA/PA33

### **Raffaello Series**



### MODEL TABLE | MAXIMUM CAPACITY(I/h)\* | LINKED TO THE RELATED PRESSURE (bar)

MODELS	POWER kW	PRESSURE bar	150	200	250	400	600	1.000	1.200	1.500
HA/PA33	45	CAPACITY l/h	8.500	6.500	5.000	3.000	1.800	1.000	700	600

\*Values referring to products with a max viscosity of 500Cp

TECHNICAL DATA					
Plunger number	3				
Stroke (mm)	70				
Weight (Kg)	1.670				
Water consumption (I/h)	200				
Lubrication oil quantity (kg)	25				
Product inlet/outlet	Socket weld flange Øe52 Øi46 / Øe40 Øi35				

Design according to MACHINE DIRECTIVES and the HARMONIZED EUROPEAN STANDARD in force.





www.bertoli-homogenizers.com




## **Raffaello Series**



HIGH PRESSURE HOMOGENIZERS AND PLUNGER PUMPS SINCE 1974

Brand of Interpump Group



### **FEATURES**

Forged block made of Duplex, SAF2205, Self-alignment patented system, 3 Plungers made of AISI630L covered by chrome

Double stage transmission system with pendular gear reducer and trapezoidal belts and pulleys

Homogenizing group with hydro-pneumatic adjustment of the pressure for a great stability and homogenizing valves in stellite™

Conical valve seat and poppet valves made of stellite 20<sup>™</sup>

Overpressure valve, flow switch alarm on water circuit

Digital pressure transmitter, 4-20 mA, with ceramic membrane

Forced lubrication system with pressure switch, cast iron crankcase with supporting roller bearings

Terminal box and control panel for local/remote control

Friendly maintenance of the liquid end

### **OPTIONS**

Second stage homogenizing group

Forged multi-block made of Super Duplex, SAF2507

Aseptic execution

- · Sterile water generator by means of condensed steam generator • Patent pending sterile water generator by means of microfiltration
- Design suitable with: 3A, EHEDG or PHARMA
- Low roughness and electropolished wetted parts

• cGMP certificates to add to Customer Pharma Manual

Standard or Sharp Edge Homogenizing valve with different geometries, materials availability:

- Tungsten carbide
- Zirconia Oxide

• High efficiency patented homogenizing valve "Margherita"

Seat valve made of Tungstene carbide

Vibration and temperature monitoring and alarm

Pumping plungers availability:

- HVOF chromium carbide jet coat treatment
- AL2O3, Integral ceramics

#### Electric power board

- for Fixed or Variable capacity
- Remote Control by 4-20 mA signal
- Fully Automatic pressure control by means of PLC

Inlet and outlet connections:

- DIN 11851, Tri-clamp, SMS
- High pressure outlet
- Option upon request

Explosion proof design

Sound-proof design

\*\*\*Technical specifications are not mandatory and subject to change without notice



BERTOLI - Brand of INTERPUMP GROUP S.p.A. Via Giambattista Vico, 2 - 42124 - Reggio Emilia - Italy Tel. +39 0522 948011 - Fax +39 0522 948080 info@bertoli-homogenizers.com - www.bertoli-homogenizers.com